



What you'll need

Measure for your blind in just a few steps. You'll need:

- A tape measure - metal ones are best
- A pencil and paper – or download our handy template

When you measure

- You can measure for your blind in centimetres or inches. Measure to the nearest millimetre if you're using centimetres. Measure to the nearest sixteenth of an inch if you're using inches.
- **Whatever type of blind you're measuring for, follow our instructions precisely and don't make any adjustments for fittings and headrails.**
- Look out for the position of window handles and tiles and the proximity of adjacent walls and furniture.
- We recommend fixing to the outside of a recess. If you want your fabric panels bunch to sit on the wall adjacent to the window (to one side for left or right bunch, or both sides for a split bunch) you will need to take this into account. Panel widths are 30cm, 45cm or 60cm. If you do not have enough room for the fabric panels to sit on the adjacent wall, please be aware that the panels may cover some of the window when they are drawn back.

Decide where you want your blind to hang

How you measure depends on where you want your blind to go. It can hang:

- On the **inside of your window** (this is called the **recess**).
- On the **outside of your window** (this is called an **exact** fitting).

All our blinds can be fitted into the front of your window frame or wall, or into the top lintel. We would recommend choosing the outside of your window recess and fixing to your ceiling to make the most of this contemporary product.

For large rooms that need to be split into different areas Panel blinds can be used as room dividers. If you do choose to use your Panel blind as a room divider, measure for an outside recess (exact measurement) and fix the headrail to your ceiling.

Simply click on the links below to view instructions.

[Measure for a blind that hangs inside the window](#)

[Measure for a blind that hangs outside the window](#)

Measure for a blind that hangs inside the window (the recess)

Whatever type of blind you're measuring for, follow our instructions precisely. Don't adjust your measurements to allow for fittings and headrails – we do all that for you.

Step 1


Measure the width of the inside of the window from wall to wall in the 3 places shown opposite (for large Panel blinds we recommend measuring in 5 places). Write down the **shortest** measurement.

Step 2

Measure for the **length of your blind** in the 3 places shown opposite. The **length** (also called the **drop**) is the **measurement from the top of the inside of the window to the window sill or floor**. Write down the **shortest** measurement.

Step 3

Save the shortest measurements in [My Web-Blinds](#) for reference or [shop for blinds now](#).



Measure for a blind that hangs outside the window (exact fitting)

Whatever type of blind you're measuring for, follow our instructions precisely. Don't adjust your measurements to allow for fittings and headrails – we do all that for you.

Step 1

Measure the width by measuring from left to right of where you'd like your blind to be. Write down the measurement.

Step 2

Measure for the length of your blind by measuring from the top of where you want your blind to be, to the bottom. The length is also called the drop.

Step 3

Save the shortest measurements in [My Web-Blinds](#) for reference or [shop for blinds now](#).

Questions about measuring?

Call us on 0845 604 9611

Email enquiries@web-blinds.com