

# how to fit and care for your **wood venetian blind**

**IN ORDER TO KEEP YOUR BLIND SAFE IN TRANSIT, THE BRACKETS ARE PACKED SEPARATELY AND ENCLOSED AT ONE END OF THE BOX. PLEASE CHECK THOROUGHLY BEFORE DISCARDING ANY PACKAGING.**

## aftercare

To ensure your Wood Venetian blind stays looking its best for many years to come, follow the straightforward operating and cleaning instructions below:

### **Operating Instructions**

- One cord on the Wood Venetian operates the height of the blind
- The other cord operates the angle of the slats
- To raise the blind, pull the cord down until the blind reaches your desired height
- To lower the blind, pull the cord across the face of the blind to release the cordlock and let the cord slide through your fingers
- Pull the other cord to adjust the angle of the slats
- Slats should be in the open position when raising or lowering the blind

### **Cleaning**

- Your Wood Venetian should only be cleaned with a dry lint-free cloth

### **WARNING**

IN THE INTEREST OF SAFETY, PLEASE KEEP ALL PULL CORDS AND CHAINS OUT OF THE REACH OF CHILDREN. MOVE COTS, BEDS AND OTHER FURNITURE AWAY FROM BLINDS AND INSTALL SAFETY DEVICES SUCH AS CLEATS AND CORD TIDIES TO LIMIT ACCESS TO CORDS.

