


The purpose of this guide is to provide you with the information and allowances necessary to fit three blinds into the windows of a square bay. Following this guide will ensure that the blinds fit as neatly as possible, without clashing. **Always use a metal tape measure when measuring to ensure that your measurements are as accurate as possible.**

The 'Depth' of your chosen blind is simply the distance the blind sticks out from where it's fitted. You'll need to know this depth to make the correct allowances when measuring. The minimum allowance for depth is 75mm (when top-fixing, or using the standard face-fixing brackets we send) but if you're face-fixing then there are longer brackets available by request:

Bracket Type	Depth
Top-Fix	75mm
75mm Face-Fix (Standard)	75mm
90mm Face-Fix	90mm
110mm Face-Fix	110mm




Top-Tip


Always check the width of each window in three places, just as you would for an ordinary recessed window. Bay windows are prone to movement and you may find that the widths vary even if at first glance they all look the same. It is always the smallest of three measurements that you should be working with. **Always use a metal tape measure when measuring.**

1



MEASURING



Then, measure how far any obstructions (such as window handles) protrude from the frame. You'll need to add this measurement to your blind depth. **You need to account for obstructions on all three windows.**



It's important to make sure that your blinds will provide adequate privacy and shading, so for this option, measure the width of your window frames, from the corner to the glass. If this measurement is less than the total depth (blind depth + obstruction depth) you're allowing for each blind then we recommend selecting a different blind type.



Measure the full width of all three windows, right into the corners of the frame. Make sure you measure the sides separately, as they can vary in width slightly.



Measuring the drop is simple, just measure from the top of where the blinds will be fitted, down to where you'd like the bottom to rest (usually the sill). You will need to make an allowance to ensure the louvres don't brush against the sill - **we recommend reducing the drop you've measured by 15mm.**

Continued on Next Page

Handle Depth = 27mm
Left width = 845mm
Centre width = 1215mm
Right width = 849mm
Drop: 1230mm - 15mm = 1215mm
Blind Depth = 75mm
TOTAL Depth = 102mm

Now that you have all of your measurements, you can make the necessary adjustments you'll need to order. First, add your blind depth to your handle depth. **This total depth is going to be the distance from the window frame to the front of the blinds.**

For this option, you'll be reducing the width of all three blinds, as each needs to make space for the others next to it. You'll reduce the side blinds by 1x your total depth (each) and the centre blind by 2x the total depth (as the centre blind is making space for a blind at each side). The drop does not need to be adjusted.

CENTRE: Corner-to-Corner - Total Depth x2 = Width to Order | Select 'Exact Fitting'

LEFT / RIGHT: Corner-to-Corner - Total Depth x1 = Width to Order | Select 'Exact Fitting'

EXAMPLE

	Corner-to-Corner	Total Depth	Width to Order	
CENTRE BLIND:	1215mm	- 102mm x2	=	1011mm Exact Fitting
LEFT BLIND:	845mm	- 102mm	=	743mm Exact Fitting
RIGHT BLIND:	849mm	- 102mm	=	747mm Exact Fitting